


# PRO250-500-750-1000

Despiece  
Spare Parts

Documentación técnica  
Technical documentation



	Referencia Reference	Descripción Description	Observaciones Notes
1	<b>RACK-SCH1000G-A</b>	Estructura / Structure RACK-SCH1000G	✓
2	<b>RACK-SCH1000G-B</b>	Tapa frontal / Frontal cover RACK-SCH1000G	✓
3	<b>FRONTAL-PRO</b>	Frontal equipos / Front part PRO250/500/750/1000	✓
3a	<b>RACK-PRO200G-C</b>	Tapa pantalla / Screen cover RACK-PRO200Gr	✓
4	<b>RACK-SCH1000G-D</b>	Tapa superior / Up cover RACK-SCH1000Gr	✓
5	<b>RACK-SCH1000G-E</b>	Tapa trasera / Back cover RACK-SCH1000G	✓
6	<b>RACK-SCH1000G-F</b>	Tapa lateral derecha / Right side Cover RACK-SCH1000G	✓
7	<b>RACK-SCH1000G-G</b>	Tapa lateral izquierda / Left side Cover RACK-SCH1000G	✓
8	<b>PCPRO</b>	Cuadro maniobra / Control unit PRO250/500/750/1000	✓
8a	<b>BAND-RACKSCH100G</b>	Bandeja soporte P954D armario PRO galvanizado / SupportP954D in PRO boxes	✓
9	<b>FC250G</b>	Modulo fuente conmutada / Power board SCH250	✓