



## PHRX-P DESPIECE / SPARE PARTS

- 1 ref. CS-1001-PHRX – carátula / mask
- 2 ref. TECLADO-C – teclado / keyboard
- 3 ref. CL81Z x 4u – tornillos tapa / cover screws
- 4 ref. CONCEPT-TAPA – tapa / cover
- 5 ref. TCH2.9X9.5 x 4u – tornillos placa de control / control board screws
- 6 ref. P906/6 – placa de control / control board
- 6a ref. P926 – placa pH / pH board
- 7 ref. JUNTA01 – junta / joint
- 8 ref. TCH4.2X16 x 4u – tornillos radiador / radiator screws
- 9 ref. CONCEPT-BASE – base / base
- 10 ref. M25JSL – prensaestopas / compression gland
- 11 ref. M20JSL – prensaestopas / compression gland
- 12 ref. M16JSL – prensaestopas / compression gland
- 13 ref. R13112AAA – interruptor / switch
- 13a ref. F0188LOAAA – protector de interruptor / switch protector
- 14 ref. 2337 – BNC / BNC
- 15 ref. 2337 – BNC / BNC
- 16 ref. BISAGRA-GOMA x 2u – bisagra / hinge strip
- 17 ref. KP200/288 – radiador / radiator
- 18 ref. PPP001HA1016 – bomba peristáltica / peristaltic pump
- 19 ref. PPP001HA1016 – bomba peristáltica / peristaltic pump